



Short Roof Hardtop Fitting Instructions.

The best way I have found is, fit the front screen clamp loosely to the roof (one or two threads), then slide the roof into place at a 45 degree angle over the screen surround.

Once in place tighten the 3 cap head bolts **EVENLY** i.e. 2 full turns each at a time, do **NOT** tighten any to full tightness singularly.

Also be careful not to overtighten as this will damage the roof fixings, 10 lbs ft is more than adequate. Please see the pictures below to see how each bracket is fixed.



