



Lightweight Rear Handbrake Caliper Adjustment.

Thank you for purchasing our Lightweight Rear Handbrake Calipers.

The installation of our calipers is no different than standard including the torque settings for the mounting bolts (please refer to Lotus service book).

Although the lightweight calipers should be 95% adjusted during our assembly stage, depending on the thickness of your disc rotors, finite adjustment may be required.

The adjuster is shown arrowed in the below picture.



Once you have installed the calipers, carefully turn the adjuster clockwise until the brake pads touch the disc surface.

Then turn the adjuster anti-clockwise one full turn to release the pads from the disc, this will set the pads within ~1mm of the disc surface.

Adjust the handbrake cable so the cable tensions before the cable holder arm touches the caliper body.

DO NOT ACTIVATE YOUR HANDBRAKE WHILST THE DISCS ARE VERY HOT LET THEM COOL DOWN 1ST

NB* FOR RACE USE ONLY